

TerraModeler New Features

Arttu Soininen
21.01.2020



Various Improvements

- **Display Triangles** draws triangles into design file now in counter clockwise order
- **Render only** option added to **Display Raster Triangles** level selection
 - Displays raster triangles only when a view is rendered using TerraPhoto rendering
- **Model Write Text** keyin command for writing LandXml files as part of macro:

```
model write text landxml12 d:\myproject\output\#bnumber.xml
```
- Faster preview display speed for large TIN models when zoomed in (**Display Shaded Surface, Display Triangles, Display Contours** and **Display Raster Triangles**)

